

KSI CS Series IV downward firing ceiling mount loudspeakers offer an unbelievable audio experience. All models provide wide frequency response with extended low end response, high power capacity and wide even dispersion. Applications include corporate, educational, government & retail installations. Installation is fast and easy without cutting tiles and subsequent cleanup.

CS Series IV loudspeakers are easy to install, just follow these simple instructions.

- Remove the ceiling tile where you want to place your CS loudspeaker. Remove a second ceiling tile for wiring purposes.
- Screw the supplied hooks to the rear of the loudspeaker.
- Place the grille into the grid first. Slide the CS loudspeaker up the other opening and rest it on the grille. The loudspeaker should look as it does in number 4.
- Make the wire connections to the electrical input & attach the hooks to the structure above. Make absolutely sure all connections meet all local electrical codes. Replace the open tile.



801-C



6061-CS



8081-CS



8081-CS-HP



101-CS-HP



12-1CS



1



2



3



4



5



6



7